

**PRODUCT DESCRIPTION**

ST-0808

**SPANISH TILE VALLEY INSTALLATION**



1. Cut away the bottom of the Spanish Tile Shingle to length, then cut away the top lip of the tile.



2. Fasten the top lip to the underside of the cut tile using two Tek self-tapping screws.



3. Snap the full tile onto the top of the custom cut valley tile.



4. Assemble valley tiles as shown below.

